

Directions to Install the 4' EZCrown Frame with EZCrown Corners

1. Remove all the EZCrown corners from the packaging and orient them into the corners of the room while holding them against the ceiling. While holding the corner in the proper position use a hex driver to secure the enclosed self tapping screws on both sides through the right angle bracket to the top plate. If no wood was present remove the self tapping screws and place the enclosed metal drywall anchor in the hole made by the self tapping screw.. Position the EZCorner and secure with the 2 included #8 Screws through the bracket into the drywall anchor. Complete all the corners prior to securing the EZCrown frames.
2. Mark the wall using a pencil 12" from the nailing block on each side of the EZCorner. Raise the EZCrown frame with your left hand and hold it tight to the ceiling wall interface. Line up the frame with the pencil mark, and drive the enclosed self-tapping screws to fasten the EZCrown frame to the top plate framing. Start 3/4" to the left of the first block on the right-hand side of the frame (I prefer to predrill the 1/8" holes prior to securing the frames with the self tapping screws). Place all the remaining screws 3/4"



from the left side of the remaining blocks. If the self-tapping screws will not drive past the drywall, stop and try and drive the screw on the other side of the block. It is possible that you have encountered a metal plate protector found over electrical wiring or plumbing.

3. Optional drywall anchors can be used when no or inadequate framing exists. Simply drive the drywall anchors into the predrilled holes in the EZCrown frame.

4. You are now ready to place your second EZCrown frame. Place the frame 12" from the existing

frame. Fasten all the top plate screws.

5. Continue placing the EZCrown frames until you are at most 12" from the pencil mark previously placed on either side of the EZCorner. You may need to cut the frame with tin snips. The frame should line up with the previous pencil mark placed 12" from the secured EZCorner.
6. Secure the EZCrown metal frames to the remaining walls.
7. Mark all block locations with a vertical pencil line.
8. Secure the crown molding to the EZCrown frame by hammering small finishing nails into the marked EZCrown block locations.

Tips

- You may find it helpful to use a 1/8" drill bit to predrill the top plate area on the EZCrown frame. Drill the 1/8" hole on the lower bend of the EZCrown frame, 3/4" to the left of each block.
- If drywall anchors are required, you may find it easier to insert the anchors by pre-drilling the holes into the wall and ceiling. It is easy to hold the frame up and mark all the 3/8" drywall holes. EZCrown recommends using a 1/8" drill bit. The drywall anchors are more easily placed into the drilled guide hole.
- ***EZCrown recommends that you wear gloves and eye protection when installing the product as it is in part, made with sheet metal***



Directions to Install the 4' EZCrown Frame with EZCrown Corners